



*It is important to us that your child enjoys their EasiRider push bike, please read the following notices carefully.*

## General Information

The EasyRider push bike does not comply with road traffic licensing regulations and should not be used on public roads. It is advisable to only use the EasiRider push bike on footpaths or dedicated bike routes.

The EasyRider push bike is a toy, and is not installed with lights or brakes. Children should enjoy their playtime under adult supervision at all times.

**Please dispose of all packaging in the proper manner.**

## Safety warnings

### Intended use

- The EasiRider push bike is designed for home use and is not suitable for commercial purposes.
- The EasiRider push bike is suitable for children over 2 years old.

### Risk of injury

- The EasiRider push bike must only be assembled by an adult.
- Keep the packaging material away from children. They could suffocate!
- The EasiRider push bike should only be used under adult supervision. Children are not aware of potential hazards during playtime.
- It is recommended that children should always wear a safety helmet when riding an EasiRider push bike.
- The EasiRider push bike must never be used by more than one child at a time.
- The rider should always keep both hands on the handlebars while riding the EasiRider push bike.
- The EasiRider push bike must only be used on well-maintained hard surfaces. Do not let children ride it in open terrain. It should not be used on sloping paths or surfaces.
- Do not let children ride in busy areas, such as car parks, or busy enclosed spaces, such as department stores. Choose a suitable park or a children's playground.
- The EasiRider push bike must not be used for bike jumping.
- Always make sure the rider wears sturdy shoes when riding the EasiRider push bike. Never let the rider use the EasiRider push bike wearing loose sandals, or bare foot.
- It is recommended that the rider wear light or bright-coloured clothing. They will be more visible in lighter clothing and better protected.
- Ensure the rider is aware of the hazards around them whilst riding the EasiRider bike.
- Do not hang nets, bags or other objects off the handlebars. The bike may tip over!
- Do not make any modifications to the EasiRider push bike and, should repairs be necessary, only use genuine replacement parts.
- Never add any other parts to the EasiRider push bike.
- Do not operate the EasiRider push bike if the bike is broken or in need of repair. Do not attempt to repair the EasiRider push bike yourself--straightening the bike into shape may add to the damage. Consult a specialist workshop, details available at [www.easirider.co.za](http://www.easirider.co.za).
- Regularly check all screws and bolts to make sure they are tight.

## Maintenance and use

- Clean the EasiRider push bike with a sponge or soft cloth and water only. If necessary, you can add a few drops of washing-up liquid to the water. Dry with a soft cloth after washing.
- Clean the EasiRider push bike before storing, and store it in a dry room.
- Consult [www.easirider.co.za](http://www.easirider.co.za) or the additional documentation that came with the EasiRider bike to see how to adapt the EasiRider bike for an older or younger child.